

## Installation Instructions

1. Select a site on your property. In most municipalities, it can NOT be installed in the “right of way” between the sidewalk and road. It can usually be installed between the sidewalk and your home. If you have an existing fence, post or tree, you could probably attach it to that, or use the U-Post.
2. Call Digger’s Hotline to have them check the area for underground wires. This typically takes 3-4 days for them to mark the area.
3. For home installation, a 4 foot U-post can be used, but a 5 foot U-post will be stronger. Install the post. Post should be mounted so the wide part is in the front with the narrow part with the tabs on the back.
4. Use 2 of the zip ties or worm gear clamps to fasten to the U-post. The top one should go around the poop chute just under the top piece so it has a lip to rest on. Secure it to one of the tabs on the U-Post. This will keep it from sliding down the post. The other should be fastened just above the bottom attachment for stability.



Figure 1